



# Safety Practices for Sanding, Grinding, Buffing, Lapping and Polishing Copper Beryllium Alloys

SF102 - Version 2, March, 2011

## CuBe

Copper beryllium (CuBe), in solid form and as contained in finished products, presents no special health risks. Most manufacturing operations, conducted properly on well-maintained equipment, are capable of safely processing copper beryllium containing materials. However, like many industrial materials, copper beryllium may present a health risk if handled improperly. The inhalation of dust, mist or fume containing beryllium can cause a serious lung condition in some individuals. The degree of hazard varies, depending on the form of the product, how it is processed and handled, as well as the amount of beryllium in the product. You must read the product specific Material Safety Data Sheet (MSDS) for additional environmental, health and safety information before working with copper beryllium containing materials.

### SOURCES OF EXPOSURE

**Machining** - Machining processes such as sanding, grinding, buffing, lapping and polishing are capable of generating small particles. These processes must be controlled with appropriate work practices and engineering controls. The following table provides a summary of those processes that typically present low inhalation concern (green) and those that may present a likely inhalation hazard (yellow).

Low Inhalation Concern Machining Operations		Likely Inhalation Hazard Machining Operations	
Blanking	Piercing	Abrasive Blasting	Honing
Boring	Pressing	Abrasive Sawing	Lapping
Broaching	Reaming	Brushing	Laser Machining
CNC Machining	Sawing (band or tooth blade)	Buffing	Point and Chamfer
Cutting	Shearing	Burnishing	Polishing
Deburring (non-grinding)	Sizing	Centerless Grinding	Process Ventilation
Deep Hole Drilling	Skiving	Coolant Management	Maintenance
Drilling	Slitting	Deburring (grinding)	Roller Burnishing
Filing by Hand	Stamping	Electrical Discharge Machining (EDM)	Sand Blasting
Gun Drilling	Tapping	Grinding	Sanding
Machining	Trepanning	High Speed Machining (>10,000 rpm)	Sectioning
Milling	Turning		Swaging
			Water-jet Cutting
			Wire EDM
<p>1) Operations in the “Low Inhalation Concern” category represent operations that typically release non-respirable (&gt;10 micrometer) particles, are not expected to generate significant ultra-fine particulate, and/or are not expected to result in exposures in excess of the Occupational Safety and Health Administration (OSHA) Permissible Exposure Limit (PEL).</p> <p>2) Operations in the “Likely Inhalation Hazard” category represent those operations which may release respirable (&lt;10 micrometer) particles, may generate ultra-fine particulate, may generate beryllium oxide and/or may result in exposures in excess of the OSHA PEL.</p> <p>3) This list is not all-inclusive and variation can exist within specific processes. Determine, then verify, the adequacy of engineering and work practice controls by conducting an exposure characterization of all copper beryllium processing operations.</p> <p>4) Effective ventilation, work practices and personal protective equipment use can control a “Likely Inhalation Hazard”.</p> <p>5) When evaluating operations, consideration must be given to potential exposures from activities in support of these operations such as setup, preparation, cleanup and maintenance.</p>			

## WORK PRACTICES & CONTROL MEASURES

Some combination of the following control measures may be required when sanding, grinding, buffing, lapping and polishing copper beryllium alloys:

### Wet Methods

- The proper use of machining lubricants as a flood or in heavy flows is usually an effective method for controlling the airborne generation of copper beryllium particles.
- Care should be given to lubricant containment that prevents excessive splashing onto floor areas or operators' clothing.
- Inadequate coolant flow and higher tooling speeds may require additional containment and ventilation controls.
- Please note that the recycling of liquid lubricant/coolant containing finely divided copper beryllium in suspension can result in the concentration building to a point where the particulate becomes airborne during use.
- Machining lubricant should be filtered, settled, centrifuged, or changed regularly to reduce the accumulation of fine particles.

### Exhaust Ventilation

- Local exhaust ventilation is not necessary for machining processes which produce only large (>0.0005"), non-respirable chips.
- Local exhaust ventilation must be used on dust producing operations when lubricants or coolants are not being used or are not effective in controlling the release of airborne dust.
- The type and capacity of local exhaust ventilation required will depend upon the speed of particle generation. For example: hand sanding operations produce relatively slow moving particles, while powered grinders and roto tool operations produce very fast moving particles.
- Positioning of a close capture, high velocity ventilation duct/hood at the point of particle generation on a stationary grinder is critical to the system's effectiveness. The duct/hood must be positioned as close as possible to the source and in line with the direction of particle travel.
- The dust generated when using handheld grinders or roto tools can be very difficult to control due to the random nature of particle generation. Handheld grinders and roto tools are generally used in a ventilated partial or full enclosure designed to draw particles away from the operator. Alternative methods to hand grinders such as filing or wet sanding should be used where possible.
- Disruption of the airflow in the area of a local exhaust inlet, such as by a man cooling fan, should be avoided.
- Ventilation equipment should be checked regularly to ensure it is functioning properly.
- Ventilation training is recommended for all users.
- To be effective, ventilation systems should be designed, installed and maintained by qualified professionals.

### Speeds/Feeds/Tooling

- These machining variables must be considered when determining the extent and type of engineering controls and work practices which may be required.
- Similar to the machining speed discussed above, stock feed rates can be an important factor in determining whether a process will generate airborne particles.
- Tooling condition is another important variable. Sharp-tooled machining processes generally produce only large chips while dull tooling may produce a mixture of large and smaller chips.
- Strict control of process speeds/feeds and tooling condition will assist in reducing airborne particle generation from machining processes.

### Respiratory Protection

- Whenever possible, appropriate work practices, use of local exhaust ventilation or other engineering controls are the preferred methods for controlling exposure to airborne particles. When these methods are ineffective, or are being developed and potential exposures are above the occupational limits, approved respirators must be used as specified by an Industrial Hygienist or other qualified professional.
- Respirator users must be medically evaluated to determine if they are physically capable of wearing a respirator.
- Quantitative and/or qualitative fit testing and respirator training must be satisfactorily completed by all personnel prior to respirator use.
- Users of any style respirator must be clean shaven on those areas of the face where the respirator seal contacts the face.
- Pressure-demand airline respirators are required when performing jobs where a potential for high exposure exists, such as changing filters in a baghouse air cleaning device.

**Protective Clothing**

- Protective overgarments or work clothing must be worn by persons who may come in contact with dusts, fumes or powders during activities such as grinding, sanding, furnace rebuilding, air cleaning equipment filter changes, maintenance, furnace tending, etc.
- Used disposable clothing should be containerized and disposed of in a manner which prevents airborne exposure during subsequent handling activities.
- Contaminated work clothing and overgarments must be managed in such a manner to prevent secondary airborne exposure to family or laundry personnel handling soiled work clothing.
- Never use compressed air to clean work clothing.

**Housekeeping**

- Sanding, grinding, buffing, lapping or polishing copper beryllium can deposit fine dust containing beryllium on the surfaces of the fabricated part.
- Fabricated parts should be kept clean between processing steps to avoid potential re-suspension of fine particles into the air.
- Copper beryllium machining equipment and associated support systems (e.g., dust collectors, heat treat furnaces, coolant trays and reservoirs) should be cleaned on a regular basis to prevent the accumulation of copper beryllium containing materials.
- The use of compressed air or brooms for cleaning dust must be prohibited. Such activity can result in unnecessary airborne dust exposure.
- Wet cleaning and vacuuming are effective methods for cleaning machining and support equipment.
- Rags, towels or wipes used to dry or wipe parts clean should not be allowed to dry and must be maintained in a closed container. Rags and towels should not be reused. They should be containerized and disposed of in a manner which prevents airborne exposure during subsequently handling activities.
- Portable vacuums should be of a type equipped with High Efficiency Particulate Air (HEPA) rated filters.
- Special care must be taken when using polishing or lapping compounds. Such compounds should not be reused due to the potential for cross contamination to other materials. The used compounds should not be allowed to dry out, during or after completion of the job.

**Maintenance**

- Under certain conditions the repair or maintenance of equipment can generate airborne particles.
- Protecting workers can require the use of specific work practices or procedures involving the combined use of ventilation, wet and vacuum cleaning methods, respiratory protection, decontamination, special protective clothing, and when necessary, restricted work zones.
- Detailed procedures for safely maintaining the process equipment and ventilation systems should be developed.
- All operators and maintenance personnel need to be trained in the established procedures prior to performing maintenance or service activities. The procedure should detail the use of wet methods or vacuuming, ventilation and appropriate personal protective equipment required to prevent exposure to airborne particles.

**Workplace Exposure Characterization**

- Air samples should be taken for all operations where a potential for beryllium exposure exists.
- Air monitoring is the primary method for determining the degree of exposure and effectiveness of engineering and work practice controls.
- Characterization of worker exposure should only be performed by trained personnel.

**Recycling**

- Copper beryllium machining scrap should be kept segregated from other metals to retain its higher value as a recyclable material.
- Materion Brush Inc. purchases clean, segregated copper beryllium scrap at a premium above mixed copper alloys (routine amounts of lubricant are not a problem).

**Disposal**

- Copper beryllium wastes are not considered hazardous under federal regulations.
- When spent products are declared solid wastes (no longer recyclable), they must be labeled, managed and disposed of, in accordance with federal, state and local requirements.
- Some copper beryllium products contain specific metals (e.g., chromium, lead) that are regulated waste materials.
- Used polishing or lapping compounds should be maintained in a moist condition (no free liquid) during collection and disposal, by double bagging in plastic to prevent it from drying out and potentially becoming airborne. The bags should be placed in a DOT approved container and appropriately labeled prior to shipment.



## ADDITIONAL INFORMATION

The information contained in this Safety Facts applies only to the subject referenced in the title. Read the MSDS specific to the products in use at your facility for more detailed environmental, health and safety guidance. MSDSs can be obtained by contacting the Materion Brush Inc. Product Safety Hotline at (800) 862-4118 or visit our website at [www.materion.com](http://www.materion.com).

Additional information can also be obtained by contacting a Materion Brush Inc. Sales Representative or:

Product Stewardship Department  
Materion Brush Inc.  
6070 Parkland Boulevard  
Mayfield Heights, OH 44124  
(800) 862-4118